

# 62 x 72mm

## CDS-6IP

### PRAWIDŁOWA KONFIGURACJA KANAŁU PRACY

Moduły radiowe CDS-6IPeco, CDS-6IP/SMA, CDS-6IP Multi domyślnie ustawione są w trybie Slave (jako nadajniki).

Moduł radiowy, który będzie pracował jako odbiornik należy ustawić w trybie Master (NVR/DVR) oraz w polu „Kanał” wybrać odpowiedni, konkretny kanał pracy... (inny niż AUTO).

#### Zalecana kolejność uruchomienia:

- \* Ustaw tryb pracy MASTER lub SLAVE i wciśnij "Zapisz"
- \* W Odbiorniku sprawdź częstotliwości wolne ( aby zeskanować częstotliwości odbiornik przestaw na chwilę na tryb Slave)
- \* Ustaw i zapisz konkretny kanał pracy.

UWAGA nie stosuj ustawień AUTO!

W przypadku problemów z transmisją proszę w pierwszej kolejności zmienić nr kanału pracy na inny.

### PROPER CONFIGURATION OF THE WORKING CHANNEL

The radio modules CDS-6IPeco, CDS-6IP / SMA, CDS-6IP Multi are set defaults in Slave mode (as transmitters).

Set the radio module that will work as a receiver in the Master mode (NVR / DVR) and set chosen operating channel in "Channel" field ... (other than AUTO).

#### The recommended order of settings to start:

- \* Set the mode SLAVE or MASTER and press "Save"
- \* Check the frequencies available in the Receiver (to scan the frequencies set the receiver for a moment in slave mode)
- \* Set and save a specific operating channel

NOTE: Do not use AUTO settings!

In case of problems with transmission, please first change the channel number to another one.



**POMOC  
TECHNICZNA**  
tel.: 505 272 224

Polish,  
all day  
service assistance.

